CR006 Sweex External Card Reader All-in-1 USB 2.0

Introduction

- Do not expose the Sweex External Card Reader All-in-1 USB 2.0 to extreme temperatures. Do not place the device in direct sunlight or in the direct vicinity of heating elements.
- Do not use the Sweex External Card Reader All-in-1 USB 2.0 in extremely dusty or moist surroundings.
- Protect the device against powerful shocks or jolts - they may damage the internal electronics.
- Never attempt to open the device yourself - it will cause the warranty to lapse.

Software installation under Windows 2000, XP and Vista

No drivers are required for use under Windows 2000, XP and Vista. You can start using the card reader straight away without installing the software. The software installation causes icons to appear next to the drive letters of the card reader, which correspond with your media card (see picture). This software can only be used under Windows 2000 or XP.

Insert the Sweex CD-ROM in the CD-ROM player in order to install the software. The CD-ROM will start automatically and a menu will appear. Select “Install Software 2000 and XP”.

User manual

Connect the card reader to a free USB port. Windows will automatically install the card reader. You can access the cards in the card reader via "My Computer" (My computer).

Warranty

All Sweex products are warranted for three years. We do not grant support or warranties for any software and/or (rechargeable) batteries included. Settlement of guarantee only takes place via the dealer where you have purchased the product in question.

The rightful owner has and retains title to all brand names and related rights mentioned in this manual.